

Gränsfors® Broad Axes

The pictures below show the angle from the user's side, i.e. you are holding the axe, looking down the handle at the poll or the butt of the axe head.



Swedish Broad Axe
Model 1900 Straight
For Left or Right Handed Folks



Double-Sided
Sharpened
No: 4804801



Reversed Scissors-
Sharpened
No: 4804802
Bevel Face on Left Side



Reversed Scissors-
Sharpened
No: 4804803
Bevel Face on Right Side



Swedish Broad Axe
Model 1900 Left-Angled
For Right Handed Folks



Double-Sided
Sharpened
No: 4804811



Reversed Scissors-
Sharpened
No: 4804812
Bevel Face on Right Side



Straight Scissors-
Sharpened
No: 4804813
Bevel Face on Left Side



Swedish Broad Axe
Model 1900 Right-Angled
For Left Handed Folks



Double-Sided
Sharpened
No: 4804821



Reversed Scissors-
Sharpened
No: 4804822
Bevel Face on Left Side



Straight Scissors-
Sharpened
No: 4804823
Bevel Face on Right Side



SCHROEDER

LOG HOME SUPPLY, INC.

"Your Log Home Hardware Store"

Ask Us! **1-800-359-6614**

www.loghelp.com